



Instruction Manual of TengYun Electric Carbinet Basket




Scan the code on your
cell phone to view

- The instructions apply to model TXT、TSM、TSW-A、TSW-B machine
 - It is recommended to have a professional master to guide the installation
-


Product Size



Battery holder



Installation Procedures





- ① Place the machine into the cabinet and leave 60mm at the front edge. Power on the power adapter and plug it into the power socket.

- ② Press both sides of the box with your hands, touch the touch bar on the puller, lift it to 10cm away from its original position, lock a screw into both the left and right sides.


Screw installation holes

Touch switch



- ③ Touch again to lower the machine to the bottom, lock the screws on both left and right sides one by one to complete the installation.

Closet Layout



Parts List

24V 5A power supply (x1)	Installation screws (x1)
Teng yun lift basket (x1)	No.7 batteries (x3)
Installation instructions (x1)	

Others Sheet

Tengyun Parameter Specification Sheet

Mode	Teng yun TST600/700/800/900
Power supply	Input 110-240V 50HZ Output DC 24V
Maximum storage weight	20KG
Duration of rising	Around 8 seconds
Duration of dropping	Around 8 seconds

Countermeasures to Malfunction

Status	Cause	Counter measures
Non-operation	The power outlet has failed to provide electricity	Turn on the power
No rising	The weight of the objects stored has exceeded 20KG	$\leq 20\text{KG}$
Inaction	Check the battery in the holder	Replace battery

Warning Instructions



Any unauthorized dismantling and priming, repair, and transformation is prohibited. Do not touch the moving body part by the technician when the machine is running; otherwise, personal injury may be caused.



Be sure to use a separate 110-240V 50HZ power outlet, and do not use an extension cord. Non-professionals please do not open the circuit board.



Do not overload items over "20KG", otherwise there is a risk of machine failure or falling, which may be a hazard.



Do not splash water upwards. There is a risk of short-circuit due to water entering the machine. If electrical items, kitchen utensils must be washed and dried before hanging. Please avoid the risk of short-circuit caused by dripping water.

After-sales Service

Maintenance guarantee: Except for man-made damage (such as improper power supply access, self - disassembly with out authorization, etc.) during the guarantee period, in accordance with the instructions, not installed in accordance with the instructions, not used in accordance with the instructions (such as for industrial or commercial purpose) or force majeure (such as natural disasters, public hazards, abnormal voltage, improper transportation, etc.) and other understandable outcomes, failure, and damage caused by factors beyond the company's obligation, the company will provide free warranty service.

Address for Maintenance Service:

Telephone Number:

Fax Number:

Free maintenance within 5 years from the date of purchase.

Well - Installed and Works Well:

Yes ☐ No ☐

Installation Signature:

Date:

After-sales Follow-up Sheet

1.The contents of the warning instructions have been informed. ☐Yes ☐No

2.The contents of the installation manual have been informed. ☐Yes ☐No

3.The operation of functions and maintenance have been informed. ☐Yes ☐No

4.Good performance of the product has been confirmed. ☐Yes ☐No

Client Signature:

Date

Product Model	Customer	State of Purchase
Address	TEL	

Attention: After - sales services should be carried out according to the date of this sheet.